Crane - CV

TLILIC0012 Licence to operate a vehicle loading crane (capacity 10 metre tonnes and above) (CV)



Course Delivery

FACE TO FACE - this is a private course for your group of min 4 to max 6 people and is delivered using your vehicle loading crane. Training can be delivered at your site providing you have adequate resources, or at our training centre in Wetherill Park.

Vehicle Loading Crane Trucks cannot be hired so no public courses are available at this time. If you do not have a group of 4-6 people, you could consider gaining a C2 licence instead. TLILIC3008 Licence to operate a slewing mobile crane up to 20 tonnes.

Course Duration

4 days (3 days training plus 1 day assessing)

(the course duration depends on group size and level of any existing skills and knowledge of participants)

Course Cost

\$1.500 per person ast-free

Course cost is based on minimum 4 to maximum 6 people per course.

[A SafeWork NSW HRW licence fee is additional and payable by each successful applicant at Australia Post Office].

Course Prerequisites

Participants must be over 18 years of age, be able to speak and understand English; understand technical concepts and mathematical equations; and provide 100 points of Identification as per SafeWork NSW requirements. If a participant fails to bring 100 points of Identification a re-booking fee of \$100 will be charged for assessment to be re-scheduled

How do I determine if my Vehicle Loading Crane has an over 10 metre tonnes capacity?

To calculate the metre tonne rating of your crane, you need to:

- 1. Refer to your crane's load chart.
- 2. Determine from the load chart the MAXIMUM LOAD your crane can lift.
- 3. Determine the MAXIMUM RADIUS it can lift the MAXIMUM LOAD.
- 4. Multiply together these 2 numbers (Metres x Tonnes)
- 5. If the answer is equal to or greater than 10, then you require a license to operate your Vehicle Loading Crane.

Course Overview

This course and licence is a legal requirement for anyone who operates a vehicle loading crane (over 10 metre tonnes).

During this course, operators are trained and assessed against the High Risk Work Licensing requirements as per Work Health and Safety Regulations.

Course Content

- Compliance with WHS licensing legislation.
- · Communicate and work safely with others in the work area.
- Risk assessment and management procedures (particular awareness of the risks associated with overhead powerlines/electrical cables, ground conditions, crane tipping and demolition sites).
- Pre-operational checks, positioning, stabilising, set up, operation, post-operational checks of a vehicle loading crane, lifting and transferring of loads within capacity of the crane.
- Techniques for estimation of load weights.

Course Outcomes

On successful completion of training and assessment, participants will receive a Statement of Attainment for TLILIC0012 Licence to Operate a Vehicle Loading Crane (capacity 10 metre tonnes and above), and will be eligible to apply for a National Licence to Perform High Risk Work (CV Class).

High Risk Work (HRW) Licences are valid for 5 years from the date of issue.

To receive a SafeWork NSW issued HRW licence, participants MUST lodge their licence application form at an Australia Post outlet together with a passport sized photo and pay the prescribed SafeWork NSW processing fee within 60 days of the final HRW assessment. Failure to lodge your paperwork on time will result in you being an unlicensed operator and further training and/or assessing fees will apply after the 60-day period.

Please refer to other relevant information on Dogging / Dogman licence requirements.

Gantry Crane (Pendant-Type)

TLID3043 Shift loads using gantry equipment



Course Duration

4 hours

Course Cost

\$1,650 per session (GST free)

This course is only delivered at your site using your gantry crane equipment and the above cost is based on a group of up to 10 participants per session.

Course Prerequisites

Participants must be over 18 years of age, be able to speak and understand English, understand technical concepts and provide suitable identification.

Course Overview

A National High Risk Work Licence is <u>not</u> required to operate a bridge or gantry crane that is controlled from the ground by a pendant and has three or less powered operations. However, in accordance with the WHS Act and Regulations 2011 under Primary Duty of Care, a PCBU must provide information, training, instruction or supervision that is necessary to protect all persons from risks to their health and safety arising from work carried out as part of the conduct of the business or undertaking.

Gantry crane training is a half day, nationally accredited course in the safe operation of a remote / pendant (or pendulum) operated gantry crane is provided at your site, using your equipment, for groups of up to 10 participants. Both theory and practical training is provided together with an assessment of participants' skills and knowledge.

Course Content

- Definitions and licensing requirements
- · Pre-operational inspection and safety checks
- Hazard identification / Risk assessment
- · Planning the lift
- · Transferring the load
- · Use of lifting gear
- Shutdown procedures
- · Emergency procedures

Course Outcomes

All successful participants meeting the assessment criteria will be issued a Statement of Attainment - TLID3043 Shift loads using gantry equipment.

What is NOT covered in this course?

If your type of equipment has more than 3 powered motions or is a "cabin controlled" gantry crane, then your operator will require a CB licence to operate it. If "slinging" techniques are required to move a load, you will need a qualified dogman with a DG licence to sling the load. This course does not cover these requirements, but please contact us for or other course information should you need a CB or DG licence.

For booking enquiries on this course, please contact our Head Office 1300 262721 or email us your details with the form below.

Refresher - Forklift

TLID2010 Operate a Forklift (Refresher Training)



Course Delivery

FACE TO FACE - at our site in Wetherill Park (see our course calendar for scheduled dates)

FACE TO FACE - at your site (providing you have adequate training areas, resources and participants)

Course Duration

4 hours

Course Cost

\$1,200 per session (GST free) for a group of up to 6 people

Course Prerequisites

Participants must have a valid Australian High Risk Work forklift licence class LF.

Course Overview

Forklift refresher training is aligned to the accredited unit of competency TLID2010 Operate a Forklift and is a half day (approx. 4 hours) training session conducted at your site (or ours) for already licensed operators. Training sessions are for a maximum of 6 people per group. Operators attending a 'refresher' course MUST produce their current forklift licence and proof of identification on the training day. Training will not be conducted without such evidence.

If you do not have a valid forklift licence, you must enrol in a formal training course (TLILIC2001), delivered by a Registered Training Organisation (such as Cobra Training Services). When you have achieved sufficient skills and competencies, you will be eligible for a LF licence assessment by a SafeWork NSW qualified assessor.

Forklift refresher training should be conducted on a regular basis and is designed to update the operator's theory knowledge; refresh practical skills, and improve operating techniques/procedures on the forklifts.

Benefits of training include: reinforces safe work practices, provides updates and changes to legislation, increases productivity and bottom line and assists in minimising the risk of damage/injury to property and persons.

Course Content

- Revision of forklift operators' theory knowledge and practical skills
- Hazard identification and risk assessment plan work
- Conduct routine checks conduct pre and post operational checks
- · Shift loads safely
- Shut down and secure forklift truck
- · Assessment of the safe application of knowledge and skills to workplace tasks

Course Outcomes

On successful completion of this course, participants meeting the assessment criteria will be issued a Statement of Attainment in TLID2010 Operate a Forklift.

Telehandler (Gold Card)

RIIHAN309E Conduct Telescopic Materials Handler Operations



Course Delivery

FACE TO FACE - at our site in Wetherill Park (see our course calendar for scheduled dates)

FACE TO FACE - at your site (providing you have adequate training areas, resources and participants)

Course Duration

6-8 hours'

PLEASE NOTE: *Course duration may vary based on training group size, prior experience (if any) and the number of attachments you are being trained on.

Course Cost

\$495 per person (GST free)

This course can be delivered at our site or yours.

For courses conducted at **our** site, we will supply the Telehandler equipment (including fork tyne and crane jib attachments), and there is no minimum number of participants required to join a public course. See belowfor scheduled course dates and Other Important Information.

For courses delivered at your site, you must supply the Telehandler equipment (and attachments you wish to be trained on) and a minimum of 4 participants is required.

Course Prerequisites

Participants must be over 18 years of age, be able to speak and understand English; understand technical concepts; and provide suitable identification. A forklift licence [LF] is desirable, but not essential.

Please note: Telescopic Handlers with greater than three tonnes lifting capacity and fitted with a crane jib attachment, require a High Risk Work licence to operate them in most states (Class CN, C2 or above). This course does not cover High Risk Work licensing. If you require a HRW licence to operate your telehandler combination, please advise us so we can book you into the appropriate course.

Course Overview

A telescopic materials handler or telehandler, is a mobile all terrain multi-purpose machine fitted with a variable height/reach telescopic boom and a lifting attachment. The most common attachment are forks, but telehandlers can be fitted with a variety of attachments for different types of loads.

Some other attachment types available are:

- Work Platforms
- · Earth moving buckets
- · Crane/Lifting Jibs

In NSW, a High Risk Work (HRW) Licence is <u>not</u> required to operate a Telehandler with fork attachments regardless of lifting capacity*, however in accordance with the WHS Act and Regulations 2011 under *Primary Duty of Care*, a PCBU must provide information, training, instruction or supervision that is necessary to protect all persons from risks to their health and safety arising from work carried out as part of the conduct of the business or undertaking. A Gold Card provides evidence of formal information and training for operators of telescopic material handlers.

Course Content

This course covers all aspects of operating a telescopic materials handler:

- · Planning and preparing for operations.
- Conducting pre-operational checks.
- · Operating the telehandler.

- · Attaching, securing, lifting, carrying and placing materials and loads.
- · Selecting, fitting and removing attachments.
- Relocating the telescopic material handler from one site to another.
- Machine maintenance and cleaning.

Who should do this course?

The information in this course is appropriate for people operating telescopic materials handlers at worksites in:

- · General and civil construction? all fields.
- · Surface Mining, drilling and extractive industries.
- Transport/warehousing/logistics and waste recycling/recovery.

Course Outcomes

Participants successfully meeting the assessment criteria will be issued a Statement of Attainment in RIIHAN309E Conduct Telescopic Materials Handler Operations and a Telescopic Handler Association (TSHA) Trained Operator Gold Card for the type of Telehandler and attachments you have been trained in the use of.

Other Important Information:

This course is only conducted in English, no interpreters or translators are permitted.

FOR COURSES CONDUCTED AT OUR SITE:

Participants MUST wear their current work uniform or neat casual clothes suitable to a warehouse or construction environment and must also wear or bring STEEL CAP/SAFETY BOOTS OR SHOES (Entry to premises will not be allowed if you fail to bring/wear steel caps)

Participants may also bring their own hi-vis vest and hard hat if they have these items, otherwise Cobra will supply loan items for the course duration.

We provide filtered water, tea, coffee & biscuits during the course, however lunch is NOT included so you will need to BRING or BUY your own lunch from nearby shops. We do have a lunch truck that visits our site at 11.50am each day and we have a few fridges where lunch can be stored.

Should you have any other questions regarding course requirements, please contact us via phone 1300 26 27 21 or email: admin@cobra1.com.au

July 2018					
Date	Course	Start time	Finish time	Location	
Mon 16	Telehandler (Gold Card)	7:30AM	2:30PM	Wetherill Park	
Mon 30	Telehandler (Gold Card)	7:30AM	2:30PM	Wetherill Park	

August 2018				
Date	Course	Start time	Finish time	Location
Mon 06	Telehandler (Gold Card)	7:30AM	2:30PM	Wetherill Park
Mon 20	Telehandler (Gold Card)	7:30AM	2:30PM	Wetherill Park
Mon 27	Telehandler (Gold Card)	7:30AM	2:30PM	Wetherill Park

September 2018	1			
Date	Course	Start time	Finish time	Location
Mon 10	Telehandler (Gold Card)	7:30AM	2:30PM	Wetherill Park
Mon 17	Telehandler (Gold Card)	7:30AM	2:30PM	Wetherill Park

Course	Start time	Finish time	Location
Telehandler (Gold Card)	7:30AM	2:30PM	Wetherill Park
Telehandler (Gold Card)	7:30AM	2:30PM	Wetherill Park
Telehandler (Gold Card)	7:30AM	2:30PM	Wetherill Park
	Telehandler (Gold Card) Telehandler (Gold Card)	Telehandler (Gold Card) 7:30AM Telehandler (Gold Card) 7:30AM	Telehandler (Gold Card) 7:30AM 2:30PM Telehandler (Gold Card) 7:30AM 2:30PM

November 2018				
Date	Course	Start time	Finish time	Location
Mon 05	Telehandler (Gold Card)	7:30AM	2:30PM	Wetherill Park
Mon 19	Telehandler (Gold Card)	7:30AM	2:30PM	Wetherill Park
Mon 26	Telehandler (Gold Card)	7:30AM	2:30PM	Wetherill Park

December 2018				
Date	Course	Start time	Finish time	Location
Mon 10	Telehandler (Gold Card)	7:30AM	2:30PM	Wetherill Park
Mon 17	Telehandler (Gold Card)	7:30AM	2:30PM	Wetherill Park

Vehicle loading crane (under 10 metre tonnes)

Course Type: TLID3033 Operate a vehicle-mounted loading crane

(for under 10 metre tonnes capacity)

Course Duration: 4 hours

Participants: Min 5 - Max 8 people

Course Cost: \$330 per person (gst-free) or \$1,650 per session for less than 5 people

Additional Costs: \$22 per person (inc GST) for proof of training photo card

\$TBA travel fees may be incurred if we need to travel outside of Sydney metro area.

\$TBA course surcharge may apply to courses conducted outside of 6am-6pm or on

Saturdays.

On-site course requirements:

Training is delivered <u>at your site</u> using your equipment. You are required to supply an under 10 metre tonne capacity vehicle-mounted loading crane which is in good working order with up to date maintenance log books and appropriate loads to move for practical training. A classroom with chairs, tables and power supply is also required for theory training. These resources must be available for the course duration. We can also deliver this <u>at our</u>

site using your crane equipment.

Secure a Booking: Once we have discussed and agreed to mutually convenient training dates, to secure our

services, you will need to complete a course booking form which we will email to you.

Course Prerequisites: Participants MUST be over 18 years of age and provide suitable identification.

 $\label{participants} \mbox{ MUST be able to speak and understand English and understand technical} \\$

concepts.

Please note that this course is only conducted in English.

Course Delivery: Face to Face - Training can be delivered at either your site or ours, however you must

provide the vehicle-mounted loading crane truck and suitable loads to move, at either

location, for the course duration.

Course Overview: This unit covers the operation of a vehicle-mounted loading crane of under 10 metre tonnes

capacity. Both theory and practical training and competency assessments are provided within this course. It includes positioning and stabilising for crane operations, operating the crane, monitoring lifting conditions, packing up the crane and completing job records.

Course Content:

- Compliance with WHS licensing legislation
- · Communicate and work safely with others in the work area
- Risk assessment and management procedures (particular awareness of the risks associated with overhead powerlines/electrical cables, ground conditions, crane tipping and demolition sites)
- Pre-operational check, positioning, stabilising, set up, operation, post-operational
 checks of a vehicle loading crane including all functions to their maximum extension in
 the lifting and moving of loads to the safe working rated capacity of the vehiclemounted loading crane under 10 tonne capacity in conjunction with other associated
 personnel



Course Outcomes: All participants meeting the assessment criteria will be issued a Statement of Attainment

for TLID3033 Operate a vehicle mounted loading crane.

Other Info: This course is designed for operators of a vehicle-mounted loading crane with under 10

metre tonnes capacity, if your vehicle loading crane has <u>over</u> 10m tonnes capacity, you are required to hold a valid HRW crane licence either CV or above, which is not covered in this course. Please read the following documents regarding how to determine if your crane has

an over or under 10 metre tonnes capacity and lifting gear and licensed Dogman

requirements.

Do I need a High Risk Work Licence to operate my Vehicle-Mounted Loading Crane?

Multiply the SWL (t) x the working radius (m) for that SWL = metre tonnes from the centre line of slew to the centre line of hook. This calculation must be done for each safe working load (SWL) on the load chart. If any calculation equals 10 metre tonnes lifting capacity or greater, the crane operator will require a High Risk Work Licence. Please refer to our CV course for HRWL information or contact us on 1300 26 27 21 or email admin@cobra1.com.au

Working at Heights

RIIWHS204D Work Safely at Heights

Course Delivery

FACE TO FACE - at our site in Wetherill Park (see our course calendar for scheduled Work Safely at Height dates)

FACE TO FACE - at your site (providing you have adequate training areas, resources and participants)



1300 26 27 21

Course Duration

1 day (approx. 7 hours)

PUBLIC Course Cost

\$225 (gst-free) per person - see our training calendar for available course dates

PRIVATE Course Cost

\$1,800 (gst-free) this daily rate applies for a private group booking of up to 8 participants for courses delivered at your site or ours - contact us to discuss available dates

Course Prerequisites

Participants must be able to speak and understand English and provide suitable identification.

Course Overview

Working at Heights training course is suitable for any person who is required to work at any height. The course covers all aspects of safe access to heights, legislative requirements, selection use and maintenance of personal protective equipment (including correct use and fitting of safety harnesses), along with practical exercises of setting up fall arrest systems and the rescue of a suspended casualty.

Height safety training includes an overview of legislation relating to working at heights, introduction to hazards and risks, correct use of harness and recovery procedure for fall arrest.

Course Content

Theory component includes:

- Work at Height Regulations / PPE regulations
- Health and Safety at Work Act
- AS/NZ and EN Standards
- · Hazard Analysis and Risk Assessment
- Work restraint and positioning
- Fall Arrest
- Inspection and record keeping procedures

Practical component includes:

- · Identification and inspection of equipment using samples
- The correct fitting of harnesses
- The correct use of ladders, lanyards, anchor straps
- The Gotcha Rescue System
- The correct and safe storage of equipment

Course Outcomes

By the end of this working at heights training course, participants will be able to: identify work requirements, identify work procedures and instructions for the task, access and install equipment, perform work at heights, clean up work area and rescue suspended persons. Satisfactory completion of this course will result in the awarding of a Statement of Attainment in the Nationally Recognised Unit of Competency RIIWHS204D Work Safely at Heights.

July 2018				
Date	Course	Start time	Finish time	Location
Fri 20	Working at Heights	7:30AM	3:30PM	Wetherill Park

August 2018				
Date	Course	Start time	Finish time	Location
Fri 10	Working at Heights	7:30AM	3:30PM	Wetherill Park
Fri 24	Working at Heights	7:30AM	3:30PM	Wetherill Park

September 2018				
Date	Course	Start time	Finish time	Location
Fri 07	Working at Heights	7:30AM	3:30PM	Wetherill Park
Fri 21	Working at Heights	7:30AM	3:30PM	Wetherill Park

October 2018				
Date	Course	Start time	Finish time	Location
Fri 05	Working at Heights	7:30AM	3:30PM	Wetherill Park
Fri 19	Working at Heights	7:30AM	3:30PM	Wetherill Park

November 2018				
Date	Course	Start time	Finish time	Location
Fri 02	Working at Heights	7:30AM	3:30PM	Wetherill Park
Fri 16	Working at Heights	7:30AM	3:30PM	Wetherill Park
Fri 30	Working at Heights	7:30AM	3:30PM	Wetherill Park

December 2018				
Date	Course	Start time	Finish time	Location
Fri 14	Working at Heights	7:30AM	3:30PM	Wetherill Park
Fri 21	Working at Heights	7:30AM	3:30PM	Wetherill Park

Yellow Card (Scissor/Boom Lift)

RIIHAN301D Operate elevating work platform



(this is <u>not</u> a traffic controller yellow card course - this course is for operators of Boom Lift NATIONALLY RECOGNISED under 11m, Scissor and Vertical Lift type EWPs)

ARE YOU LOOKING FOR THE HIGH RISK WORK LICENCE - EWP BOOM LIFT OVER 11M COURSE? CLICK HERE

Course Delivery

FACE TO FACE - at your site using your EWP equipment and training room with groups of 6-12 people

FACE TO FACE - at our site in Wetherill Park. See our course calendar for scheduled Yellow Card training dates and times and OTHER IMPORTANT INFO below.

Course Duration

6 hours

(Depending on the size of the training group and level of knowledge and skills of the participants). No minimum number of participants required to join a public course.

Minimum of 6 participants for 'at your site' group training.

Course Cost

\$295 per person gst-free (includes boom under 11m, vertical and scissor lifts at our site) as at 18/1/17

Course Prerequisites

This course is only conducted in English, no interpreters or translators are permitted.

Participants must be over 18 years of age, be able to speak and understand English and provide suitable identification such as a driver's licence.

Course Overview

In accordance with the WHS Act and Regulations 2011 under Primary Duty of Care, a PCBU must provide information, training, instruction or supervision that is necessary to protect all persons from risks to their health and safety arising from work carried out as part of the conduct of the business or undertaking. Depending on which type of ewp equipment you receive training on, a Yellow Card can provide 'evidence of training' for the following equipment: Boom Lift (under 11m), Scissor Lift, Vertical Lift, Trailer Lift or Truck Mount. This accredited course structure is both specific to your particular model of equipment and to Elevating Work Platforms in general.

Cobra Training Services delivers regular public training courses for boom lift (under 11m), vertical and scissor lifts at our site in Wetherill Park on a weekly basis.

We can also provide this service at your site for groups of 6-10 people if you have your own appropriate EWP equipment and resources. We do not charge any call out fees.

Course Content

This yellow card training course covers the operation of elevating work platforms in the resources and infrastructure industries. It includes planning and preparing for operations, working from the platform, carrying out maintenance and cleaning up. Topics covered include:

- · knowledge of the requirements, procedures and instructions for operating elevating work platforms
- implementation of requirements, procedures and techniques for the safe, effective and efficient completion of operating elevating work platforms
- · working with others to undertake and complete the operation of elevating work platforms that meet all of the required outcomes
- · consistent timely completion of operating elevating work platforms that safely, effectively and efficiently meet the required outcomes
- Verbal/Written and Practical Assessment

Course Outcomes

All participants meeting the assessment criteria will be issued a **Statement of Attainment** for **RIIHAN301D Operate Elevating Work Platform**, together with an Elevating Work Platform Association 'Trained Operator' Yellow Card, specific to the type of EWP you have been trained in the use of; i.e. Boom Lift under 11m, Scissor Lift, Vertical Lift, Trailer Lift or Truck Mount.

Please note: This course does not cover BOOM TYPE LIFTS <u>OVER</u> 11m Platform Height. These types of EWPs require a National High Risk Work [HRW] Licence, issued by the WHS Regulator in each state (e.g. SafeWork NSW). We also provide training and assessments for this boom lift over 11m HRW licence requirement in our over 11m boom lift EWP course. **Please ask us for more details.**

Other Important Information:

This course is only conducted in English, no interpreters or translators are permitted.

FOR COURSES CONDUCTED AT OUR SITE:

Participants MUST wear their current work uniform or neat casual clothes suitable to a warehouse or construction environment and must also wear or bring STEEL CAP/SAFETY BOOTS OR SHOES (Entry to premises will not be allowed if you fail to bring/wear steel caps)

Participants may also bring their own hi-vis vest and safety hamess if they have these items, otherwise Cobra will supply loan items for the course duration.

We provide filtered water, tea, coffee & biscuits during the course, however lunch is NOT included so you will need to BRING or BUY your own lunch from nearby shops.

Should you have any other questions regarding course requirements, please contact us via phone 1300 26 27 21 or email: admin@cobra1.com.au

July 2018				
Date	Course	Start time	Finish time	Location
Thu 19	Yellow Card (Scissor/Boom Lift)	7:30AM	2:30PM	Wetherill Park
Thu 26	Yellow Card (Scissor/Boom Lift)	7:30AM	2:30PM	Wetherill Park

August 2018				
Date	Course	Start time	Finish time	Location
Thu 02	Yellow Card (Scissor/Boom Lift)	7:30AM	2:30PM	Wetherill Park
Thu 09	Yellow Card (Scissor/Boom Lift)	7:30AM	2:30PM	Wetherill Park
Thu 16	Yellow Card (Scissor/Boom Lift)	7:30AM	2:30PM	Wetherill Park
Thu 23	Yellow Card (Scissor/Boom Lift)	7:30AM	2:30PM	Wetherill Park
Thu 30	Yellow Card (Scissor/Boom Lift)	7:30AM	2:30PM	Wetherill Park

September 2018	3			
Date	Course	Start time	Finish time	Location
Thu 06	Yellow Card (Scissor/Boom Lift)	7:30AM	2:30PM	Wetherill Park
Thu 13	Yellow Card (Scissor/Boom Lift)	7:30AM	2:30PM	Wetherill Park
Thu 20	Yellow Card (Scissor/Boom Lift)	7:30AM	2:30PM	Wetherill Park
Thu 27	Yellow Card (Scissor/Boom Lift)	7:30AM	2:30PM	Wetherill Park

October 2018					
Date	Course	Start time	Finish time	Location	
Thu 04	Yellow Card (Scissor/Boom Lift)	7:30AM	2:30PM	Wetherill Park	
Thu 18	Yellow Card (Scissor/Boom Lift)	7:30AM	2:30PM	Wetherill Park	
Thu 25	Yellow Card (Scissor/Boom Lift)	7:30AM	2:30PM	Wetherill Park	

November 20	018			
Date	Course	Start time	Finish time	Location
Thu 01	Yellow Card (Scissor/Boom Lift)	7:30AM	2:30PM	Wetherill Park
Thu 08	Yellow Card (Scissor/Boom Lift)	7:30AM	2:30PM	Wetherill Park
Thu 15	Yellow Card (Scissor/Boom Lift)	7:30AM	2:30PM	Wetherill Park
Thu 22	Yellow Card (Scissor/Boom Lift)	7:30AM	2:30PM	Wetherill Park
Thu 29	Yellow Card (Scissor/Boom Lift)	7:30AM	2:30PM	Wetherill Park

December 2018				
Date	Course	Start time	Finish time	Location
Thu 06	Yellow Card (Scissor/Boom Lift)	7:30AM	2:30PM	Wetherill Park
Thu 13	Yellow Card (Scissor/Boom Lift)	7:30AM	2:30PM	Wetherill Park
Thu 20	Yellow Card (Scissor/Boom Lift)	7:30AM	2:30PM	Wetherill Park